


1.




Click and download the firmware update.

2.



Download and save onto a USB drive.

3.




Extract the firmware file from the zip file.


4.




Plug USB into the machine.




On your machine, enter the **Settings** window.




Enter the **Machine Information** window.




Enter the **Firmware Version** window.



Select how you would like to update (**Wi-Fi or USB**)



Machine screen during update.
Do not power off the machine.



**Machine screen after
update is completed.**
Restart the Machine.

